



## 13125-M INSTALLATION INSTRUCTIONS FOR: Architectural LED Wall Wash Track Light

### Safety Precautions:

1. **Read Carefully:** Prior to installation or servicing, thoroughly read and understand all safety precautions and instructions on the back side. Failure to follow these guidelines may result in serious injury, electric shock, or property damage.
2. **Qualified Installation:** It is strongly recommended that all wiring be performed by a licensed electrician. This fixture must be installed in compliance with all national and local electrical codes.
3. **Avoid Wet Conditions:** Do not handle or attempt to energize the fixture with wet hands, or while standing on wet surfaces or in water. Do not install within 10 ft or less from the nearest edge of a pool, spa, fountain, or similar location
4. **Verify Power Source:** Ensure the power source meets the fixture's requirements.



Round Canopy



Louver lens



Square Canopy



Flat lens

**WARNING:** RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY IN ACCORDANCE WITH NATIONAL, LOCAL BUILDING AND ELECTRICAL CODES. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.

## Canopy Installation

- Locate the junction box in the ceiling or wall, ensuring it contains two wires: a black (Hot +) and a white (Neutral -).
- **IMPORTANT:** Splice the wires carefully—white to white, and black to black.
- Connect the green ground wire to the green ground screw or the green wire in the junction box to ensure proper grounding.
- Once all wires are connected, carefully push the wires back into the junction box.
- Secure the mounting bracket to the junction box using two screws (A).
- Position the monopoint cover over the mounting bracket and fasten it with two screws (B).

### To Install:

- Grasp the lampholder by the mounting adapter and pull down on the adapter sleeve. Insert the contact head into the monopoint opening.
- Twist the mounting adapter approximately 90° until the sleeve tab locks securely into the monopoint opening.

**IMPORTANT:** Avoid forcing the mounting adapter in the wrong direction, as this may damage the contact assembly. If the adapter does not turn easily, twist it in the opposite direction. Ensure that the polarity tab on the adapter aligns with the polarity line on the monopoint for proper installation.

### To Remove:

- Pull down on the mounting adapter sleeve until the tab is free from the monopoint opening.
- Twist the mounting adapter 90° until the contact head is disengaged, and then remove the lampholder from the monopoint.

