

*****PLEASE SAVE THESE IMPORTANT SAFETY INSTRUCTIONS*****

This Product Must Be Installed in Accordance with the Applicable Installation Code by a Person Familiar with the Construction and Operation of the Product and the Hazards Involved

Installation recommended to be done by a professional electrician and must be in accordance with local codes of the National Electrical Code (NEC)

**TOOLS REQUIRED FOR INSTALLATION:
Wire Strippers, Flathead Screwdriver, Philips Screwdriver**

1. To prevent electrical shock, disconnect before installation or service.
2. Strip the two (2) leads from the fixture wire. Using a silicone filled connector or outdoor rated wire nuts (not supplied) connect the leads from the fixture to the main supply cable leads.
NOTE: Wire shall not be buried more than 6 inches below surface. Secure connection to the main supply cable. Always coil extra wire not used below fixture for future relocation if desired.
3. Adjust fixture to desired angle.
NOTE: When no escape outlet is provided avoid aiming fixture directly upward. When possible, set at angle to prevent rain or irrigation water from setting on lens. This is not applicable in the Well Light Series.
4. Reconnect power supply after servicing.

WARNING: TO REDUCE THE RISK OF FIRE OR INJURY TO PERSONS:

1. Lamp gets HOT quickly! Contact only switch/plug when turning on. To prevent electrical shock, disconnect power supply before servicing.
2. Do not touch lens, guard, or enclosures. Lighted lamp is Hot! Please allow fixture to cool down before servicing. Please keep lamp away from combustible materials that may burn.
3. Do not operate fixture with missing or damaged parts.

LAMP INSTALLATION / REPLACEMENT:

CAUTION: DO NOT EXCEED MAXIMUM WATTAGE MARKED ON FIXTURE LABEL.

1. To prevent electrical shock, disconnect power supply before replacing lamp.
2. Remove shroud to expose lamp.
3. Replace lamp with correct wattage and type of lamp marked on fixture label.
NOTE: DO NOT touch Halogen Lamp with bare hands. Always use the plastic bag (if available) or soft cloth when handling the lamp. Oil from skin may damage lamp.
4. Re-install shroud.
5. Reconnect power.