






**RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY IN ACCORDANCE WITH NATIONAL, LOCAL BUILDING AND ELECTRICAL CODES. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.**


### POWER FEED




### NON-POWER SUSPENSION




4" Octagon Junction Box




Wire Nut




Assembled T-grid Clips




Screw 6#\*4




Plastic Grommet




Power Cord




4" Canopy Power Feed




Cable Holder



Strain Relief Thread Nut



Aircraft Cable



2" Canopy


### Part List

- 1 Armored Cable & Connector (By Others)
- 2 Power Cord (By Others)
- 3 4" Octagon Junction Box
- 4 Wire Nut
- 5 Assembled T-grid Clips
- 6 Screw 6#\*4
- 7 T-grid ( By Others )
- 8 Plastic Grommet
- 9 Ceiling Tile (By Others)
- 10 Power Cord
- 11 4" Canopy Power Feed
- 12 Cable Holder
- 13 Strain Relief Thread Nut
- 14 Aircraft Cable
- 15 2" Canopy





**RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY IN ACCORDANCE WITH NATIONAL, LOCAL BUILDING AND ELECTRICAL CODES. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.**

### POWER FEED




### NON-POWER SUSPENSION



Wire Nut

### Part List


- 1 4" Octagon Junction Box (By Others)
- 2 Power Cord (By Others)
- 3 Wire Nut
- 4 Junction Box Crossbar
- 5 Screw PM4\*22
- 6 Power Cord
- 7 4" Power Canopy Kit
- 8 Cable Holder
- 9 Strain Relief Thread Nut
- 10 Aircraft Cable
- 11 Drywall Ceiling (By Others)
- 12 Butterfly Drywall Anchor
- 13 Crimp Stud
- 14 2" Canopy
- 15 Solid Ceiling (By Others)
- 16 Anchor
- 17 Screw PA4\*30




Junction Box Crossbar




Screw PM4\*22




Power Cord




4" Canopy Power Feed




Cable Holder




Strain Relief Thread Nut




Aircraft Cable




Butterfly Drywall Anchor




Crimp Stud



2" Canopy



Anchor



Screw PA4\*30



**RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY IN ACCORDANCE WITH NATIONAL, LOCAL BUILDING AND ELECTRICAL CODES. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.**


### IMPORTANT

1. Read all instructions.
2. Install in accordance with national and local electrical code regulations.
3. This product is intended to be installed and serviced by a qualified, licensed electrician.
4. Do not install in wet locations. For dry and damp use only.
5. Turn off electrical power before installing or servicing fixture in any way.
6. To reduce the risk of fire and overheating, make sure all connections are tight.
7. Under no circumstances can the lighting fixture be covered with heat insulation gasket or similar materials.
8. The maximum connection of each input line is 40FT (1200CM) in 120AC and 100FT (3000CM) in 277AC.

### SHOCK HAZARD



May result in serious injury or death.  
Turn power OFF at circuit breaker prior to installation or servicing.



### WIRING


CORD / SUPPLY WIRING		LUMINAIRE	
LINE	●	LINE-BLACK	●
GREEN	●	GROUND-GREEN	●
NEUTRAL	●	NEUTRAL-WHITE	●
DIM (+) VIOLET	●	VIOLET	●
DIM (-) PINK	●	PINK	●



Please isolate two dimming wires by P2 terminal individually if no need dimming; Must connect wires with corresponding colors as shown.


### PRE-INSTALLATION

#### Assemble Power Cord



### INDEPENDENT INSTALLATION

#### 1 Hang Luminaire




Screw both bottom parts of the aircraft cables clockwise and securely attach them to the top of the housing, ensuring the lights are properly suspended.



Adjust the height of luminaire

Note: Luminaire can be raised by pulling cable through the gripper and can be lowered by depressing the top cylinder on the gripper which pulls the luminaire down.

#### 2 Complete



Use the cable tie to keep the electric wire going up along with the wire rope.



**RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY IN ACCORDANCE WITH NATIONAL, LOCAL BUILDING AND ELECTRICAL CODES. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.**

### JOINER OPTIONS



Run Joiner




"L" Joiner



"V" Joiner



"Cross" Joiner



"Y" Joiner

Note: It needs 2 inputs if using "cross" and "Y" joiner.

### ACCESSORY




Silicone Seal

Note: Silicone seal is used to seal seams that may appear at both ends of luminaires when multiple connections.


### BEFORE CONNECTING

#### Disassemble Luminaires



#### Start of run (SoR):

Remove the end cap without power cord and take the LED module out.



#### Middle of run (MoR):

Remove both end caps and take the LED module out.




#### End of run (EoR):

Remove the end cap without power cord and take the LED module out.


### MULTIPLE LUMINAIRES CONNECTION

#### LINE CONNECTION


##### 1 Install joiners



##### 2 Hang luminaire and wiring – SoR



##### 3 Repeat Hang and join steps – MoR to EoR




3-1: Zip tight the power cord and the aircraft suspension cable with the cable tie.

3-2: Connect the quick connectors properly.

3-3: Insert all the LED modules into the housing from SoR to EoR in turn.

##### 4 Complete






**RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY IN ACCORDANCE WITH NATIONAL, LOCAL BUILDING AND ELECTRICAL CODES. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.**

### L SHAPE CONNECTION




For "cross" and "Y" shape or other geometric shapes, take into consideration they are all subject to the "L" shape installation. It needs 2 inputs if using "cross" and "Y" joiner.

#### 1 Install joiners




#### 2 Hang luminaire and joiners



2-1: Insert the "L" joiner into luminaire from one side and fix it with screws.

2-2: Screw both bottom parts of the aircraft cables clockwise and securely attach them to the top of the housing, ensuring the lights are properly suspended.

#### 3 Connect



3-1: Zip tight the power cord and the aircraft suspension cable with the cable tie.

3-2: Connect the quick connectors properly.

3-3: Insert all the LED modules into the housing from SoR to EoR in turn.

#### 4 Complete

